



■ 傳感器安裝

傳感器：RCM

傳感器束帶：BM**









代號 內徑	A	B	C	D	E
6	15	21	10	16	28
10	17	23	10	16	28
16	20	29	10	16	28







■ 重量表

氣缸重量

單位：g

型號	基本重量 MCMJ-11-B	行程 15 mm MCMJ-11-B	基本重量 MCMJ-11-D	行程 15 mm MCMJ-11-D	基本重量 MCMJ-11-R	行程 15 mm MCMJ-11-R
內徑						
$\phi 6$	—	—	—	—	18	2
$\phi 10$	21	4	24	4	23	3
$\phi 16$	46	7	52	8	46	7

配件重量

型號	LB	FA	T	Y	I	插銷
內徑						
$\phi 6$	9	5	—	—	—	—
$\phi 10$	9	5	14	22	16	1
$\phi 16$	21	13	54	17	21	3